


WT-1 Wireless Keypad 2nd Station (REAR VIEW W/ TEXT UP)




(*) Connect to the vessel's battery (-)

(+) #12 or 24 VDC from a source which remains on while the vessel is in service and is turned off with the vessel's main D.C. power switch. Power requirement is about 75 milliamperes/keypad. Use a 250ma fuse.

(**) Must provide 12 or 24 VDC power to the yellow 'AUX' wire (see page 8 in the manual for 'AUX' switch options). Turn this switch ON, and a 10 second calibration sequence initiates in order to synchronize the tabs and the indicators at full retract position. The Wireless will show blinking LEDs which denotes tabs up. Turning this switch OFF initiates another sync/retract sequence for tabs up at trips end. Fuse with 250ma.

WT-1 Wireless Keypad 1st Station (REAR VIEW W/ TEXT UP)



(+) #12 or 24 VDC from a source which remains on while the vessel is in service and is turned off with the vessel's main D.C. power switch. Power requirement is about 75 milliamperes/keypad. Use a 250ma fuse.


(**) Connect to the vessel's battery (-)

(**) Must provide 12 or 24 VDC power to the yellow 'AUX' wire (see page 8 in the manual for 'AUX' switch options). Turn this switch ON, and a 10 second calibration sequence initiates in order to synchronize the tabs and the indicators at full retract position. The Wireless will show blinking LEDs which denotes tabs up. Turning this switch OFF initiates another sync/retract sequence for tabs up at trips end. Fuse with 250ma.

Operational Note:
When moving from one station to a new station, it is recommended to press the 'ALL UP' button at the new station. The reason for this is both WT Wireless Keypads communicate with the WR power module individually and not between each other. This will allow the new station keypad to initiate an 'ALL TABS UP' and calibrate the LED indicators with the power module tab position.

Note 1: Wireless Control Models:

- WTR-111 = Single Station 12vdc with 1 Keypad and 1 Power Module
- WTR-121 = Dual Station 12vdc with 2 Keypads and 1 Power Module
- WTR-211 = Single Station 24vdc with 1 Keypad and 1 Power Module
- WTR-221 = Dual Station 24vdc with 2 Keypads and 1 Power Module



Lectrotab Dual Station Wireless Control Installation Wiring Diagram 06-25-09